Koshi batten detail Endcap detail 🛕 Profile: Rectangle 30x100 Weight: 1.361 kg/m Batten thickness: 2.0mm End cap thickness: 2.0mm End cap: Painted aluminium 30 30.5 20 100 100.5 2 95. 2

			Product Name				Project Name	Date	Page	Scale	Projection
3			KOSHI RECTANGLE 30X100					07/2021	1 of 2	1:1	♦□
<u> </u>	Install	Never strike extrusion directly with a hammer or rubber mallet. Use a pine plank	Approval Check Drawing Design		Design		Covet International		T +613 9398 8128		

Install lever strike extrusion directly with a harmfiner of rubber mailer. Use a pline plank photos Check brawing between the tool and the extrusion to avoid surface damage or denting.

End Caps | Screw fix to secure cap to batten.



27 / 131 Hyde St Yarraville VIC 3013 T+613 9398 8128 info@covet.com.au www.covet.com.au

Koshi Batten Installation Guide 🛕 🛕



- Aluminium can be damaged if mishandled. Never strike directly with a hammer or rubber mallet. Use a pine plank between the striking rubber mallet and the extrusion to avoid surface damage or denting.
- Cut aluminium with a drop saw using an aluminium blade.
- Always cap ends of extrusions with supplied end caps or a flashing to avoid moisture ingress.
- Metal end caps (painted) must be screwed to the extrusion.

Screw fix or apply exterior grade adhesive (Sikaflex) to secure cap to batten.

- All end caps can only be applied to straight 90 degree cuts. They cannot be applied to angle end cuts.
- Ensure appropriate screws are used to suit the substrate you are fastening to. It is important to use stainless steel or bi-metal screws for all metal surfaces impacted when fastening (i.e. furring channels, top hats, steel frames). This will prevent galvanic reaction between the screw/substrate and aluminium extrusion.
- Fasten at maximum 1 metre spans. Please contact Covet for further information.

			Product Name				Project Name	Date	Page	Scale	Projection
3			KOSHI BATTENS					07/2021	2 of 2		♦ □
2	Install	Never strike extrusion directly with a hammer or rubber mallet. Use a pine plank between the tool and the extrusion to avoid surface damage or denting.		Check	eck Drawing Design		COVOT	Covet International		T +613 9398 8128	

Yarraville VIC 3013

www.covet.com.au