


Koshi batten detail

Profile: Plank 120x13 (round edge)

Weight: 0.858kg/m Batten thickness: 1.2mm







			Product Name				Project Name	Date	Page	Scale	Projection
3			KOSHI PLANK 120X13 (round edge)					11/2021	1 of 2	1:1	♦□
2		Never strike extrusion directly with a hammer or rubber mallet. Use a pine plank between the tool and the extrusion to avoid surface damage or denting.	Approval Check Drawing Design			Design	COVOT	Covet International 27 / 131 Hyde St		T +613 9398 8128	
Λ	End Caps	Screw fix or apply exterior grade adhesive (Sikaflex) to secure cap to batten.					COVEL	Yarraville VIC 3013		info@covet.com.au www.covet.com.au	

Koshi Batten Installation Guide 🛕 🛕



- Aluminium can be damaged if mishandled. Never strike directly with a hammer or rubber mallet. Use a pine plank between the striking rubber mallet and the extrusion to avoid surface damage or denting.
- Cut aluminium with a drop saw using an aluminium blade.
- Always cap ends of extrusions with supplied end caps or a flashing to avoid moisture ingress.
- Metal end caps (painted) must be screwed to the extrusion.
- All end caps can only be applied to straight 90 degree cuts. They cannot be applied to angle end cuts.
- Ensure appropriate screws are used to suit the substrate you are fastening to. It is important to use stainless steel or bi-metal screws for all metal surfaces impacted when fastening (i.e. furring channels, top hats, steel frames). This will prevent galvanic reaction between the screw/substrate and aluminium extrusion.
- Fasten at maximum 1 metre spans. Please contact Covet for further information.

\vdash	т			Product Name KOSHI PLANKS				Project Name	Date	Page	Scale	Projection
								,				
\Box	3\								11/2021	2 of 2		● □
	37											<u> </u>
1/	<u>ል</u>		Never strike extrusion directly with a hammer or rubber mallet. Use a pine plank between the tool and the extrusion to avoid surface damage or denting.	Approval	Check	Drawing	Design	⊿ ©	Covet International		T +613 9398 8128	
									27 /	131 Hvde St	info@	ocovet.com.au
1 /	End Cap		Screw fix or apply exterior grade adhesive (Sikaflex) to secure cap to batten.				'			aville VIC 3013		covet.com.au

www.covet.com.au