

## Koshi batten detail

## Profile: Plank 200x20 (square edge)

Weight: 1.905 kg/m Batten thickness: 1.5mm End cap thickness: 2.8mm



## Endcap detail 🛕



		Product Name	Project Name	Date	Page	Scale	Projection
3		KOSHI PLANK 200X20		07/2021	1 of 2	1:1	<del>♦</del> 母
$\overline{}$	Never strike extrusion directly with a hammer or rubber mallet. Use a nine plank	Approval Check Drawing Design		_			

Install letween the tool and the extrusion to avoid surface damage or denting.

End Caps | Screw fix or apply exterior grade adhesive (Sikaflex) to secure cap to batten.

covet

Covet International 27 / 131 Hyde St Yarraville VIC 3013 T+613 9398 8128 info@covet.com.au www.covet.com.au

## Koshi Batten Installation Guide 🛕 🛕



- Aluminium can be damaged if mishandled. Never strike directly with a hammer or rubber mallet. Use a pine plank between the striking rubber mallet and the extrusion to avoid surface damage or denting.
- Cut aluminium with a drop saw using an aluminium blade.
- Always cap ends of extrusions with supplied end caps or a flashing to avoid moisture ingress.
- Metal end caps (painted) must be screwed to the extrusion.
- All end caps can only be applied to straight 90 degree cuts. They cannot be applied to angle end cuts.
- Ensure appropriate screws are used to suit the substrate you are fastening to. It is important to use stainless steel or bi-metal screws for all metal surfaces impacted when fastening (i.e. furring channels, top hats, steel frames). This will prevent galvanic reaction between the screw/substrate and aluminium extrusion.
- Fasten at maximum 1 metre spans. Please contact Covet for further information.

$\vdash$				Product Name				Project Name	Date	Page	Scale	Projection	
				Froduct Name				riojectivanie	Date	ruge	ocule	Trojection	
	3			KOSHI PLANKS					07/2021	2 of 2		⊕□	
Г	<u> </u>		Never strike extrusion directly with a hammer or rubber mallet. Use a pine plank	Approval	Check	Drawing	Design		Covet International		T +613 9398 8128		
		<u>-</u>	between the tool and the extrusion to avoid surface damage or denting.					COVAL	27 /	27 / 131 Hvde St		info@covet.com.au	
L	ብ l	End Caps	Screw fix or apply exterior grade adhesive (Sikaflex) to secure cap to batten.	ո.						aville VIC 3013		covet com au	

www.covet.com.au